



#### Scope of Supply/Bill of Material & Mounting Drawings

Part Number: H-NC750-02-01-SL / H-NC750-02-02 Part Description: Radiator Guard – HONDA NC750X (2012-2020)

#### Installation / Parts List / Bill of Material for Mounting

No.	Description	Quantity	Torque * (N-m)	Remarks **
1	Radiator Guard	1		
2	Washer M6	1		
3	Nut M6	1		
4	Screw M6	1	9 - 10	Use Liquid Thread Locker
SRC D	esign uses Metric System of	Measureme	ent and all dimensior	ns are in Millimeters
* Recommended to use the Torque specified in the table				
** De	notes Usage of Liquid Threa			












Copyright By SRC Design and Specification are subjected to change




# <src










Copyright By SRC Design and Specification are subjected to change

Page 2

# ≪SRC

**Mounting Instructions** 



#### Step 1:


Remove the Fastener in the top side of the Radiator, as shown and the one holding the bottom clip.

The same screws has to be used for mounting the Radiator Guard, along with other hardware as per the BOM.

### Step 2:

Orient and Align the Radiator Guard (1), as shown, and in-line with the Top flap with the mounting point, as shown in Red colour, and Slip-in the Hexagonal head bolt, which was removed earlier and secure the threads.

The Small Radiator Pin which projects from the bottom side of




the Radiator, has to be passed through the hole in the bottom


side of the Radiator Guard, as

shown.

Copyright By SRC Design and Specification are subjected to change







Step 3:


Insert the Screw M6 (4) - 1 off, Washer M6 (2) - 1 off, through the hole in the other side of flap and through the mounting hole (as shown in Red colour) and secure it using Nut M6 (3) from the other side.

Ensure symmetry of Orientation and no fouling with Outer or peripheral surfaces of the Radiator and tighten it fully.

## Step 4:

Mount the Clip which was removed in Step 1 and secure it using the fastener back and align it to the Radiator pin, as shown in the drawing on the left-hand side.

The final mounted condition of the Radiator Guard is as shown in the drawing on the Right-hand side.



Copyright By SRC Design and Specification are subjected to change

Page 4

## < SRC

#### **General Instructions**

1. We request you to pay attention to the Mounting Instructions in this document and follow the step-by-step procedures.

2. This Mounting Instruction manual is a "Do It Yourself" (DIY) fitment manual of the Accessory part to the Vehicle. We have prepared this based on our experience and knowledge, related to the Vehicle, Part and its functional aspects.

3. SRC cannot guarantee the interchangeability of the parts to any other manufacturer's accessory part. It is advised to the User, to inspect and ensure the original state of all other Vehicle parts.

4. We request you to bear in mind, that the Installed part can change the driving behaviour and/or the stability during driving or any other dynamic conditions.

5. If you have the appropriate tools and another person to assist you in the mounting, it will help.

6. After Completion of the Mounting and before taking on a First ride, Ensure and Check all functions of the Vehicle. It is always advised to check loosening of the fasteners after the first 50 kilo meters of ride and at regular intervals.

7. We are showing here the Scope of Supply/Installation/Parts list & BOM from SRC

8. To the maximum extent possible, our design use the current Mounting/Fitment of the Original Equipment, so that Installation of these accessories will not affect the Payload or Function of the Vehicle or the Part on which it is mounted to protect it

9. If any additional modifications are to be done, prior to the fitment of the accessories, it will be explicitly specified in the instruction sheets.

Copyright By SRC Design and Specification are subjected to change

